



**Cleaning  
+ Care**

# Neat Appearance

A neat appearance is always positive and this applies also to technical devices like a camera, that very often accompanies its owner to various places. Reliable, proper functioning of photographic equipment is even more important. Especially the camera, (hopefully) being a reliable companion on holidays, at events or family celebrations is very often exposed to the effects of weather conditions, that can be the cause for breakdowns of camera functions or of inferior picture quality, which can result in our losing documents of some irretrievable occasions.

These are good reasons to give special attention to the „cleaning & care“ issue and to complement the camera equipment with some important accessories.

The camera is an optical device with „a visual function“ which is why it always needs to be „clear and clean“. Lenses and optical attachments, viewfinder eyepieces, displays and monitors should be free from dust, dirt, finger prints, water marks etc. Cloths, sprays, brushes and compressed air are the appropriate tools for the cleaning and care of your optical surfaces and these should be with you wherever you go.



**6316**  
**„Typhoon“ Blower Bellows**

Large rubber bulb for strong blowing effect.  
Rugged front air nozzle, rear air duct valve.  
Easy to handle.  
Cleaning brush included.



**6672-74**  
**Cleaning Cards**

For mechanical cleaning of memory card contacts in digital cameras, MP3 players, PDAs, card readers and adapters. Removes fouling and dust and dirt particles by moving the card back and forth several times in the card slot. Package includes micro fibre cleaning cloth for camera body, display etc.

**6672 CompactFlash Cleaning Kit**

Includes one cleaning card, 10 exchangeable cleaning inserts for at least 20 cleaning procedures and a micro fibre cleaning cloth.

**6673 Memory Stick Cleaning Kit**

Includes two cleaning cards equipped with a special 3M cleaning tape and a micro fibre cloth. Each card can be used up to ten times.

**6674 SD-Card/MultiMedia Cleaning Kit**

Includes two cleaning cards with a special 3M cleaning tape and a micro fibre cloth. Each card can be used up to ten times.





**6315**  
**Blower Brush**

Round brush with large rubber blower bulb.



**6314**  
**Blower Brush**

Flat brush with large rubber blower bulb.



**6311**  
**Blower Brush**

Round brush with rubber blower bulb.



**6301**  
**Lens Brush**

In plastic tube. With lipstick twist mechanism, not lubricated.



**6308-09**  
**„Clear Gear“ Compressed Air**

For touch-free dust removal from optical, fine mechanical and electronic equipment and components. With spray valve and capillary tube for inaccessible places

**6308:** „Clear Gear“ compressed air can, 200 ml, propane/butane mixture.

**6309:** „Clear Gear“ compressed air can, 400 ml, non-inflammable fluorethane mixture, special high pressure version.

**6663**  
**Cleaning Set**

For wet cleaning of sensitive surfaces: lenses, LCD screens, glasses, binoculars etc. Cleaning pen with slanted square shaped felt tip, soaked with environment-friendly cleaning fluid without alcohol, silicone or ammoniac. Surface-gentle.

Comprises:

- Cleaning pen with safety cap
- Micro fibre cloth 14 x 18 cm (5.5 x 7.1 in.), for rubbing down and polishing



**6662**  
**Display and Optics Cleaning Kit**

Includes „Display Cleaner“ pump spray and a micro fibre cleaning cloth. Alcoholic cleaning fluid in 25 ml (0.8 floz.) pump spray dispenser for well directed application on the area to be cleaned and subsequent removal using the micro fibre cloth. Leaves no residues. Suitable for optical and plastic glass.



**6666**  
**Display and Optics Cleaning Pen**

Cleaning pen with conductive fibre brush on one side and a microfibre cloth tip on the opposite side. Brush for removing dust and static charges. Cleaning cloth tips for wet cleaning for fingerprints and greasy spots. Cleaning liquid included. Exchangeable carrier for large or small cloth tips. Ten tips each are included.



**6362/65/67**  
**Cotton Gloves**

To prevent fingerprints on prints, negatives, optical glass, etc. 100 % cotton, washable at all temperatures.

**6362:** One pair, size 15

**6365:** One pair, size 12 (standard size)

**6367:** Three pairs, size 12





**6697**  
**Cleaning Set**

Consisting of optical-glass cleaning fluid, optical-glass cleaning paper and blower brush.



**6699**  
**Cleaning Set**

Consisting of lens cleaning paper, cleaning leather and blower brush. For cameras, lenses, binoculars, spectacles etc.



**6695**  
**Optical-Glass Cleaning Paper**

Special paper, free from silicon, for cleaning optical glass.



36 rolls of  
Optical-Glass Cleaning Paper

Pack of 4 tolls of 40 sheets each.



**6328**  
**Micro Fibre Cleaning Cloth**

Completely fluff-free, grease-absorbing cloth for gentle, yet effective cleaning of optical lenses (glasses, lenses, magnifiers), but also suitable for CDs, records, photos, slides, TV/monitor screens, etc. Washable without loss of cleaning properties. Hemmed edges. In different colours.



Assortment  
of 25 x 6328

Size: 20 x 20 cm (7.9 x 7.9 in.)



**6330**  
**Rodenstock Micro Fibre Cloth**

Completely fluff-free, grease-absorbing cloth for gentle, yet effective cleaning of optical lenses (glasses, lenses, magnifiers), but also suitable for CDs, records, photos, slides, TV/monitor screens, etc. Takes up all moisture, oil and grime. Machine or hand washable without loss of cleaning properties. Colour: White, in a black pocket. Size: 17.5 x 15 cm (6.9 x 5.9 in.)

Display holding 30 cloths.

**6361**  
**Antistatic Cloth**

Lint-free, especially treated cloth.  
Dimensions: approx. 24 x 30 cm (9.4 x 11.8 in.)



**6363**  
**Special Antistatic Cloth**

High-grade lint-free cloth with chainstitched border for cleaning and antistatic treatment of films, glass, and lenses. Also suitable for phonograph records, plastic parts and plastic-coated surfaces.  
Dimensions: approx. 24 x 30 cm (9.4 x 11.8 in.)



**6364**  
**Leather Cleaning Cloth**

Genuine leather. For cleaning optical glass.  
5 pcs.



**6323**  
**Contact Cleaner**

For cleaning oxidized and dirty battery contacts and contact surfaces in electric devices. Handy pencil form with twist-out fibreglass tip.



**6678**  
**„Xerapol“ Plastic Polish**

Polish paste for removing scratches from acrylic glasses, for example on shooting tables or light boxes. Also suitable for acrylic glass parts of cars, motorbikes, caravans, mobile homes, furniture etc. Not suitable for matt acrylic surfaces.

Tube with 50 g (1.8 oz) of polish paste.



**6679**  
**Acrylic Glass Cleaner**

Special cleaning spray for acrylic glass. Environment-friendly. Removes fingerprints, residues of grease, felt marker and other contaminations. Streak and smear free cleaning. Anti-static effect. Bio-degradable.

Pump spray bottle with 250 ml (8.5 fl.oz.).





## 6320 Compressed Air Cleaner

Easy-to-use and environment-friendly compressed air cleaner with compressor, e.g. for service workshops and labs, studios and wherever dust has to be eliminated quickly and thoroughly. Quick-release connection for air hose. Adjustable pressure switch, display on pressure gauge. Automatic operation: Turns on automatically when the storage tank pressure is below 4 bar and automatically shuts itself off when full (at 6 bar). Very low noise level (30 dB/A at 1 m distance). Safety valve, water separator.

Motor power: 135 Watt  
Aspiration: 20 l/min  
Pressure tank: 1.5 l  
Spiral air hose: approx. 5 m (16 ft) long  
Weight: approx. 17 kg (37 lbs.)  
Dimensions: approx. 44 x 18 x 28 cm  
(17.3 x 7.1 x 11 in.)